



INSTALLATION QUARRY TILE

PROCESS

- A. CLEAN & DRY.
- B. REPAIR.
- C. APPLY BASE.
- D. APPLY TOPCOAT.

A. CLEAN & DRY

1. Clean quarry tile with Dawn Dishwashing liquid and water. Use deck brush. Do not use mops.
2. Rinse thoroughly.
3. Dry with floor blower.

B. REPAIRS

1. Fill cracks and worn out grout with repair filler (Drylock Fast Plug is suggested).

C. APPLY BASE

1. Mix Part A with Part B. Mix ratio is 1:1.
2. Also add 10% - 20% acetone for easier workability.
3. Caution: After mixing, allow 3 minutes of "induction time."
4. Caution: Working time (pot life) is 30 minutes. After 20 minutes or so, any remaining BASE in the bucket must be disposed in the garbage.
5. Pour over quarry tile. Spread thin with roller. Then backroll evenly.
6. Allow 6 hours for tack-free dry time.

Note: By using our special accelerator, tack-free dry time can be reduced to 3 hours. Beware that working time will be shortened. Add at 1% of w/v after step 3.

D. TOPCOAT

1. Mix Part A with Part B. Mix ratio is 1:1.
2. Add color. Add 1% by volume.
3. Add anti-skid additive. 8 -15% by volume is suggested. Adjust as desired.
4. Caution: Working time (pot life) is 30 minutes. After 20 minutes or so, any remaining TOPCOAT in the bucket must be disposed of in the garbage.
5. Pour over BASE. Spread thin with roller. Then backroll evenly.
6. Tipping off – To achieve a showroom smooth finish, run a brush very gently across the surface immediately after you have applied the topcoat.
7. Allow 4 hours dry time for light foot traffic.

505 S. Villa Real Drive Suite 206
Anaheim CA 92807 | +1-714-283-8990



Note: Full cure is 3 days.

Note: By using our PA Retarder, working time can be increased in hot and humid climates, but cure time will not be affected.